

ASSEMBLY INSTRUCTIONS

STAMPED STEEL LABOR SAVER TABLE BASE

(2000-BPS SERIES "X" STYLE BASE SHOWN)

(4) - Adjustable Pronto Glides

M12 x 60 Hex Head Bolt

M12 Split Washer

M12 Flat Washer

Glide Assembly Instructions

Base Plate Assembly
Stamped Steel 22" Base Plate "X" Style
2022-BPS Shown

INSTRUCTIONS:

- 1) With the Column Assembly Upside Down, Align the Center Bolt Hole of the Base Plate with the Bolt Hole of the Column.
- 2) Slide the Split Washer and Flat Washer onto the M12 Hex Bolt and then Thread the Bolt Thru the Base Plate and Into the Column and Tighten with a Wrench or Socket.

Column Assembly

Stamped Steel 3" Labor Saver Column with Welded 11" x 11" Top Plate
LS-3-DHS Shown