















For correct use, open the leg until the safety lock snaps completely.

Push the safety lock to open / close the leg.

ATTENTION





